

 Tyndall
FP Slave 433µm

$\Delta D = 15.0\mu\text{m}$
CTVR / the impact of manufacturing
tolerance on device

 Tyndall
SFP 2 Contact 433µm

CTVR / the impact of manufacturing
tolerance on device



 Tyndall
FP Slave 433µm

$\Delta D = 30\mu\text{m}$
CTVR / the impact of manufacturing
tolerance on device



 Tyndall
SFP 2 Contact 433µm

CTVR / the impact of manufacturing
tolerance on device